




Your Handle Type:

Andersen



- Loosen the set screw on the inside door handle. Pull off the handle. Then pull off the outside door handle with the spindle attached.
- Loosen the set screw on the outside door handle. Remove the old spindle and insert the new, longer spindle.
 Tighten the set screw.
- Install the outside handle with the new spindle back into the door.
- Install the extension. Push the inside and outside handles together gently and tighten the set screw. Make sure the handles can turn freely.
- If necessary, you may install nylon washers on one or both ends of the extension so that the handle can turn easily.