


Your Handle Type:

Kwikset Inactive



1

Because the set screw is reverse threaded, turn it **counter-clockwise** to loosen it. Remove the handle.



4

Replace the door handle. Line up the hole in the handle over the extension set screw. Turn the screw counter-clockwise until the handle is secure.



2

Slide on the extension. Line up the hole on the barrel of the extension with the set screw. Turn the screw clockwise to tighten.



3

Make sure the extension is not too long to fit inside the door handle. If it is, you may cut off the **unfinished end** of the extension; be careful not to damage the finished end.